



FIRE EXTINGUISHER IDENTIFICATION SIGNS

Standard Safety Signs

<p>Fire blanket Use for smothering fires Suitable for: Chip pan fires, Deep fat fires, Waste bin fires Suitable for: Wrapping around someone whose clothes are burning</p>	<p>Carbon Dioxide Safe for: Flammable liquids Flammable solids Live electrical equipment Not for: Wood, paper and textiles Live electrical equipment Flammable metal fires</p>	<p>ABC Powder Safe for: Wood, paper and textiles Flammable liquids Flammable solids Live electrical equipment Not for: Flammable metal fires</p>	<p>Foam Spray Safe for: Wood, paper and textiles Flammable liquids Flammable solids Live electrical equipment Not for: Flammable metal fires</p>	<p>Water Safe for: Wood, paper and textiles Flammable liquids Flammable solids Live electrical equipment Not for: Flammable metal fires</p>	<p>Fire Hose Reel Safe for: Wood, paper and textiles Flammable liquids Flammable solids Live electrical equipment Not for: Flammable metal fires</p>
W6366M (200 x 80mm)	W6265M (200 x 80mm)	W6360M (200 x 80mm)	W6361M (200 x 80mm)	W6362M (200 x 80mm)	W6365M (200 x 80mm)
<p>ABC Powder Safe for: Wood, paper and textiles Flammable liquids Flammable solids Live electrical equipment Not for: Flammable metal fires</p>	<p>Foam Spray Safe for: Wood, paper and textiles Flammable liquids Flammable solids Live electrical equipment Not for: Flammable metal fires</p>	<p>Water Safe for: Wood, paper and textiles Flammable liquids Flammable solids Live electrical equipment Not for: Flammable metal fires</p>	<p>Carbon Dioxide Safe for: Flammable liquids Flammable solids Live electrical equipment Not for: Wood, paper and textiles Flammable metal fires</p>		
W6370 ID (105 x 150mm)	W6373 ID (105 x 150mm)	W6374 ID (105 x 150mm)	W6372 ID (105 x 150mm)		

Equipment Location Signs

<p>Fire extinguisher</p>	<p>Fire alarm</p>	<p>Fire hose</p>	<p>Fire point</p>	<p>Fire phone</p>	<p>Automatic fire hose reel Instructions for use: 1. Pull out hose 2. Open nozzle 3. Open mouth 4. Aim at base of fire Not for: Live electrical equipment</p>	<p>Manual fire hose reel Instructions for use: 1. Pull out hose 2. Aim at base of fire 3. Open nozzle 4. Open mouth 5. Aim at base of fire Not for: Live electrical equipment</p>
W6490D (200 x 150mm)	W6450D (200 x 150mm)	W6495D (200 x 150mm)	W6459D (200 x 150mm)	W6451D (200 x 150mm)	W6394D (150 x 200mm)	W6395D (150 x 200mm)
<p>Fire extinguisher</p>	<p>Fire alarm</p>	<p>Fire hose</p>	<p>Fire point</p>	<p>Fire extinguisher</p>	<p>Fire hose</p>	
W6422A (100 x 100mm)	W6421A (100 x 100mm)	W6420A (100 x 100mm)	W6314A (100 x 100mm)	W6424A (100 x 100mm)	W6055PT (100 x 300mm)	W6053PT (100 x 300mm)
<p>Fire alarm call point</p>	<p>Fire alarm call point</p>	<p>In case of fire break glass</p>	<p>Fire alarm call point</p>	<p>Fire alarm</p>	<p>Fire alarm</p>	
W6054M (80 x 200mm)	W6441M (80 x 200mm)	W6410M (80 x 200mm)	W6441PT (100 x 300mm)	W6450PT (100 x 300mm)	W6459PT (100 x 300mm)	
<p>Fire hose</p>	<p>Fire extinguisher</p>	<p>Fire hydrant</p>	<p>Fire point</p>	<p>Fireman's switch</p>	<p>Fire telephone</p>	
W6053M (80 x 200mm)	W6055M (80 x 200mm)	W6454M (80 x 200mm)	W6459M (80 x 200mm)	W6483M (80 x 200mm)	W6068M (80 x 200mm)	
<p>Fire blanket</p>	<p>Sprinkler stop valve</p>	<p>Dry riser</p>	<p>Wet riser</p>	<p>Fire fighting equipment stored inside</p>	<p>It is an offence to tamper with fire fighting equipment</p>	
W6310M (80 x 200mm)	W6401M (80 x 200mm)	W6448M (80 x 200mm)	W6449M (80 x 200mm)	W6284M (80 x 200mm)	W5546M (80 x 200mm)	

The signs shown on this page are available in White Matt Rigid PVC only